

ELECTRONIC CONTROLLER


image 2/4/6 (2000)



Ref. No. : 720E

Date : 03/2005

Page : 1 of 1



Ref.	Part Description	Part Numbers
1	Plastic Cabinet	71-P51143
2	Door	71-P01038
3	PWB Assembly	
	IMAGE 2	71-P50432
	IMAGE 4	71-P50433
	IMAGE 6	71-P50434
4	Keypad	71-P50607
5	Fuse	71-P10037
6	Front Panel	71-P51141
7	Cover only	71-P51072
8	Transformer 50Hz	71-P50642

ELECTRONIC CONTROLLER

image DUAL PROGRAM


image 2/4/6



Ref. No. : 797E

Date : 03/2005

Page : 1 of 1



Ref.	Part Description	Part Numbers
1	Cabinet Assembly (less sticker).....	71-P50263
2	PWB Assembly	
	IMAGE 2	71-P50432
	IMAGE 4	71-P50433
	IMAGE 6	71-P50434
3	Fuse.....	71-P10037
4	Transformer 50Hz.....	71-P50642
5	Keypad	71-P50262